motofomo

Indian FTR 1200 and 1200 S (2019-2020) maintenance schedule table

I = Inspect (and adjust/lubricate/replace)
T = Tighten/Torque
A = Adjust (if necessary)

R = Replace
C = Clean

L = Lubricate
P = Perform

mi x 1000	0.5	2.5	5	10	15	20	25	30	35	40	45	50	
km x 1000	0.8	4	8	16	24	32	40	48	56	64	72	80	Notes
Drive Chain	I/C/L	I/C/L	I/C/L	I/C/L	R	I/C/L	I/C/L	R	I/C/L	I/C/L	R	I/C/L	
Chain Sliders			I/R	I/R	I/R	I/R	I/R	I/R	I/R	I/R	I/R	I/R	Replace as needed
Engine Oil & Filter	R			R		R		R		R		R	Inspect used oil for contaminants
Oil Lines / Oil System=	I/C/A	I/C/A	I/C/A	I/C/A	I/C/A	I/C/A	I/C/A	I/C/A	I/C/A	I/C/A	I/C/A	I/C/A	
Fuel System	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	
Air Filter		I/C	I/C	I/C	R	I/C	I/C	R	I/C	I/C	R	I/C	
Spark Plugs				I/R		I/R		R		I/R		I/R	
Engine Compression				I/A		I/A		I/A		I/A		I/A	Correct as necessary
Valve Lash Clearance						I/A				I/A			
Engine coolant												R	Replace every 5 years
Crankcase Ventilation System	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	I/T/C/A	
Evaporative Emission Control System	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	
Exhaust System	I/T/A	I/T/A	I/T/A	I/T/A	I/T/A	I/T/A	I/T/A	I/T/A	I/T/A	I/T/A	I/T/A	I/T/A	
Brake Fluid	R	R		R		R		R		R		R	Change at distanceinterval or every 2 years
Brake Pads	I/R	I/R	I/R	I/R	I/R	I/R	I/R	I/R	I/R	I/R	I/R	I/R	Replace if beyond service limit
Front Brake Lever	A/L	I/A/L	A/L	A/L	A/L	A/L	A/L	L	A/L	A/L	L	A/L	
Rear Brake Pedal	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	
Gear Shift Pedal	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	
Clutch Lever	L		I/A	L	I/A	L	I/A	L	I/A	L	I/A	L	
Clutch Cable Freeplay	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	Adjust as necessary
Control Cable Ends	I/L		I/L	L	I/L	L	I/L	L	I/L	L	I/L	L	
Fasteners	I/T	I/T	I/T	I/T	I/T	I/T	I/T	I/T	I/T	I/T	I/T	I/T	
Engine Mount Fasteners	I/T/A											I/T/A	
Steering Bearings	I	I	I	I	I	I	I	I	I	I	I	I	Lubricate as necessary
Front Forks and Front Axle	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	
Front Fork Oil	I				R			R			R		Replace at intervals or every 2 years.
Suspension Linkage, Rear	I	I	I	I	I	I	I	I	I	I	I	I	
Swing Arm and Rear Axle	I	I	I	I	I	I	I	I	I	I	I	I	
Rear Shock Absorber	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	R	
Rear Wheel Alignment	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	
Tires / Wheels	I	I	I	I	I	I	I	I	I	I	I	I	Inspect tread depth, sidewall cracking, wear patterns
Sidestand	L	I/A/L	I/A/L	I/A/L	I/A/L	I/A/L	I/A/L	I/A/L	I/A/L	I/A/L	I/A/L	I/A/L	
Battery	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	Check terminals, clean, test voltage.
Head Light	I/A	I/A		I/A		I/A		I/A		I/A		I/A	
Road Test	P	P	P	P	P	P	P	P	P	P	P	P	